

# OLY CLOCK-Must be turned on first before NHL

START GAME CLOCK	SET MAIN CLOCK	START/STOPS	GOAL SCORE	CORRECT WRONG SCORE
<b>START A NEW GAME (EVEN IF TOD IS SHOWING)</b>	SET MAIN CLOCK	START to get time to begin with PUCK HITTING THE ICE	SCORE +1 (HOME OR GUEST SECTION)	<i>If score was entered incorrectly:</i>
MENU	1200			SCORE - 1 (HOME OR GUEST SECTION)
ARROW DOWN TO NEW GAME	ENTER	STOP to stop clock with whistle		
ENTER				
		Running clock per tournament rules		
			<i>On scoresheet: Record time of goal (Period length less time on clock--time elapsed in game)</i>	
			<i>Record scoring player</i>	
			<i>Record assist(s)</i>	

# OLY CLOCK-Must be turned on first before NHL

PENALTY	REMOVE PENALTY	END OF NIGHT	TURN ON CLOCK IF OFF
PLAYER PENALTY (HOME OR GUEST SECTION)	DELETE PENALTY (HOME OR GUEST SECTION)	MENU	<i>The OLY side clock must be turned on first. Then the NHL side.</i>
Enter Player #	UP/DOWN ARROW TO THE PENALTY TO REMOVE	ARROW UP	
ENTER	ENTER	SELECT TOD	If clock is off
100 (or time set by refs or tournament)		ENTER	FLIP SWITCH TO ON ON BACK
ENTER	If the penalty is at the end of the period and carries into the next period press:	1 (FOR 12 HOUR CLOCK)	CLEAR/NO to Resume Game
	DISABLE PENALTY CLOCK	70100 FOR 7:01 (THE CORRECT TIME OF DAY)	Enter th code 4402
	before setting the close for the 1 minute between periods.	ENTER	ENTER
<i>On Scoresheet:</i>	before setting the close for the new period, press:	2 (TO DISPLAY TOD)	ENTER to accept the broadcast settings
<i>Record Player</i>	ENABLE PENALTY CLOCK	ENTER	
<i>Record Penalty</i>			
<i>Record Period</i>			
<i>Record time of penalty (Period length less time on clock--time elapsed in game)</i>			