

# NHL CLOCK-Must be turned on after OLY

START GAME CLOCK	SET MAIN CLOCK	SET TEAM NAMES (NHL)	START/STOPS	GOAL SCORE	CORRECT WRONG SCORE
<b>START A NEW GAME (EVEN IF TOD IS SHOWING)</b>	SET MAIN CLOCK	MENU	START to get time to begin with PUCK HITTING THE ICE	SCORE +1 (HOME OR GUEST SECTION)	<i>If score was entered incorrectly:</i>
MENU	1200	DOWN ARROW to MENU-ROSTER			SCORE - 1 (HOME OR GUEST SECTION)
ARROW DOWN TO NEW GAME	ENTER	Slide the sheet out for the buttons on the clock to see the keyboard.	STOP to stop clock with whistle		
ENTER		Hit space to clear the previous name and arrow back to the left.			
		Type the home team name.	<i>Running clock per tournament rules</i>	<i>On scoresheet:</i>	
		ENTER		<i>Record time of goal (Period length less time on clock--time elapsed in game)</i>	
		ENTER			
		ENTER	If the names don't display properly, start the instructions again but before entering the first team name hit:	<i>Record scoring player</i>	
		Hit space to clear the previous name and arrow back to the left.			
		Type the guest team name.	COLUMNS 48	<i>Record assist(s)</i>	
		ENTER	ROWS 8		
		ENTER	DOUBLE STROKE		
		ENTER	Then follow the rest of the instructions.		

# NHL CLOCK-Must be turned on after OLY

PENALTY	REMOVE PENALTY	END OF NIGHT	TURN ON CLOCK IF OFF	TO USE THE LARGE SCOREBOARD	
PLAYER PENALTY (HOME OR GUEST SECTION)	DELETE PENALTY (HOME OR GUEST SECTION)	MENU	<i>The OLY side clock must be turned on first. Then the NHL side.</i>	<b>THE WALL CLOCK IS THE OFFICIAL CLOCK</b>	
Enter Player #	UP/DOWN ARROW TO THE PENALTY TO REMOVE	ARROW UP		Start the camera first: Make sure the office has the large clock on and set up for the scoreboard like for high school games	Start the LiveScore App: Open the LiveScore app.
ENTER	ENTER	SELECT TOD	If clock is off		On the left hand side of the screen, enter a short team name for the home and guest teams.
100 (or time set by refs or tournament)		ENTER	FLIP SWITCH TO ON ON BACK	The laptop should be plugged in, the black cord with the white adapter plugged into the left side and the white usb cord plugged into the right side.	Scroll down and hit Submit.
ENTER	If the penalty is at the end of the period and carries into the next period press:	1 (FOR 12 HOUR CLOCK)	CLEAR/NO to Resume Game	Password is 1350	
	DISABLE PENALTY CLOCK	70100 FOR 7:01 (THE CORRECT TIME OF DAY)	Enter th code 4402		In upper right hand corner, hit Start
	before setting the close for the 1 minute between periods.	ENTER	ENTER	Make sure laptop is connected to Alice WiFi (Hockey321).	The clock should show on the big screen now.
<i>On Scoresheet:</i>	before setting the close for the new period, press:	2 (TO DISPLAY TOD)	ENTER to accept the broadcast settings	Open the Scoreboard OCR app (this is for the camera that reads the wall clock).	
<i>Record Player</i>	ENABLE PENALTY CLOCK	ENTER		Click the arrow on the side of the Load button at the upper right side of the screen.	<i>If when starting the apps they bring up an error, open up the internet and bring up Google. Then close it and restart the apps.</i>
<i>Record Penalty</i>				Pick the first option that has NDI in the name.	
<i>Record Period Record time of penalty (Period length less time on clock--time elapsed in game)</i>				Click in Start Capture on the left and the scoreboard should show on the laptop screen.	
				Minimize the app.	